



Est. UK1958
Bearmach
LAND ROVER PARTS

BA 121 / BA 121A Diff Guard Fitting Instructions.

Kit consists of:

- 1 x Diff Guard.
- 2 x Bolts.
- 2 x Nuts.
- 2 x Washers.

- 1 Offer up the diff guard to the diff and slide over the edge of the diff casing.
- 2 Tap the guard so that it is tight against the diff.
- 3 Make sure the cut out in the lip of the guard lines up with the diff drain plug.
- 4 Insert the 2 bolts into the holes, fit the washers and nuts supplied and tighten.

